



Installation Instructions for KC 7442 4-Tab Front Light Bar 04-05 Chevy 1/2 Ton Pickup 4w/d only

Thanks for choosing a KC HiLiTES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950.

Parts Included:

- | | |
|------------------------------------|----------------------------------|
| 1 - Light Bar | 1 - Drivers side frame bracket |
| 4 - 1/2 x1 " Bolts, Nuts & Washers | 1 - Passenger side frame bracket |
| 1 - Instructions | |

Installing the Bar

1. Locate the front tow hooks.
2. Remove the inside nut and lower bolt from each tow hook.
3. Position the appropriate bracket on the passenger side frame rail as shown in photo A below with the rounded end ear of the bracket forward and up.
4. Duplicate the procedure for the drivers side bracket.
5. Tighten the bolts and nuts on both sides.
6. Insert the light bar brackets through the openings in the plastic valance panel with the light bar bracket to the outside of the frame bracket previously mounted.
7. Match the two holes in the light bar bracket with the two holes in the frame bracket.
8. Insert the bolts supplied through the mating holes, apply the lock washers and hand tighten the nuts.
9. Adjust the light bar so the light tabs are parallel to the body lines of the truck. (It may be necessary to tighten the bolts a bit more than hand tighten so the bar will hold its position while adjusting.)
10. Tighten all nuts and bolts.



You're DONE! - - - - - Install your KC lights and enjoy.



IF YOU HAVE ANY PROBLEMS
OR QUESTIONS, PLEASE CALL
CUSTOMER SERVICE AT 800-528-0950